


DKNY Satiny Finish TWS Earphones



Specification

- Wireless version: V5.3
- Transmit distance: 10m
- Speaker impedance: $16\Omega \pm 15\%$
- Frequency range: 2402~2480 MHz
- Input: DC 5V / 500 mA
- Earphones battery capacity: 30 mAh x 2
- Charging Pod Battery Capacity: 300 mAh
- Charging time: 2 hours
- Play time: 26 hours with charging case
- Microphone sensitivity: $105 \pm 3\text{db}$

Product overview



1. LED of charging case
2. Touch button - MFB
3. Microphone
4. Charging port of charging case
5. Charging pin of earbud


Charging for charging case

When the charging case is connected with a charger (or computer USB port) by charging cable, the indicator will flash in orange slowly. When the charging case is fully charged, the indicator will be lit in orange. Note: when the charging case is out of battery, the earbuds will not turn on/off automatically when removed from or placed back into the charging case. In this case, turn the earbuds on/off manually.

First use & pairing


Auto Power-On & Pairing

Take the earbuds out of the charging case, the earbuds will automatically power on and enter into pairing mode.



Manual Power-On & Pairing

Touch the MFB for 2 secs on both earbuds to turn on the earbuds. (You will hear the prompt tone). The earbuds will automatically enter pairing mode.



Connect

Turn on the device's Bluetooth setting. Search for and choose "DKNY TWS" to pair, your device will show "connected".


Auto Power-Off

Put L&R earbuds back into the charging case, the earbuds will automatically power off.



Manual Power-Off

1. Touch the MFB for 10 secs on both earbuds to power off the earbuds.
2. The earbuds will automatically turn off when without pairing for 10 mins.



Control

Calls

1. Tap once MFB to answer call
2. Tap twice MFB to end call
3. Touch and hold MFB for 1s to reject call

Music

1. Tap once MFB of earbud R for volume up
2. Tap once MFB of earbud L for volume down
3. Tap twice MFB to Play/Pause music
4. Touch and hold MFB of earbud R for next track
5. Touch and hold MFB of earbud L for previous track

Voice assistant

1. Tap 3 times MFB to activate Siri/voice assistant

Reset

If you have problem to connect the earphones with your device, follow the step as below:

- Make sure all devices have turned off the wireless/BT function and the pairing record has been cleaned.
- Take the earphones out of the case, tap each earbud 5 times quickly, prompt sound will be activated, then follow the pairing step as instructed.