

Waterproof Smartwatch DT102

User Manual



Watch functions

Button:

1. Short press the button on the dial interface to enter the menu interface. Short press the button on the menu interface to exit back to the dial interface.
2. While in the menu interface, short press the button twice quickly to switch between different menu styles.
3. When in a second-level or third-level interface, a short press of the button will return to the first-level interface.
4. Long press the button to display the shutdown options. Select 'X' to cancel shutdown, or '✓' to confirm shutdown.
5. In the dial or menu interface, rotate the button to switch between different watch faces and menu pages.

Charging instructions:

Align the pins on the charging cable with the charging contacts on your device. Once properly connected, your smartwatch should display a charging screen to confirm that it's charging.

Shortcut Functions:

1. Adding shortcuts: Swipe left to find the "+" icon. Tap the icon to add part of the menu as a shortcut function.
2. Quick settings: Swipe down to view the Bluetooth connection status, time, power level, Do Not Disturb mode, brightness adjustment, and other functions.
3. Recent activities and messages: Swipe right to display the time, date, day of the week, the latest message (tap to view multiple messages), toggle Bluetooth for calls, and see some of the recently used menu functions.
4. Accessing the menu: Swipe up to enter the menu interface. Slide up and down to find and select the corresponding function.
5. Changing the watch dial: Long press the watch face interface and swipe to switch between different watch faces. Select a watch face and tap it to set it successfully.

Push messages:

1. Receiving messages: When the watch is bound to the app and notification permissions are enabled, new messages received in the mobile phone's notification bar will be pushed to the watch. The watch can save up to 10 messages. New messages will overwrite the oldest ones.
2. Deleting messages: Swipe to the bottom and press the delete icon to clear all message records.

Drop-down menu:

Swipe down from the dial interface to open the drop-down menu.

1. Status and controls: Bluetooth connection status, time display, and power display
2. Icons:
 - First icon: About.
 - Second icon: Do Not Disturb mode (applies to message notifications, not phone audio).
 - Third icon: Brightness adjustment.
 - Fourth icon: Control mobile phone music (connect to the app).
3. Additional shortcuts: Add a second page by pulling down halfway and then sliding left or right to find more shortcut features: GPS, mode selection, power-saving mode, alarm clock, flashlight, and voice assistant. In power-saving mode, the brightness display will be slightly different.

Phone/Call History:

1. Making and receiving calls: Enter the left swipe interface and click the call icon to turn Bluetooth phone on/off. To enable Bluetooth, go to "About" and turn on Bluetooth, open phone settings, search for Bluetooth, and connect to the device with the Bluetooth name and last four digits of the Bluetooth address. Once connected, you can use the watch to answer or hang up calls.
2. Call Records: The watch can save connected and dialled call records. It can store more than 50 call records, and will overwrite the oldest records when it reaches 128. Tap any call record to call back.
3. Dialling a number: Use the keypad to enter a phone number and make a call.

Notifications:

When the watch is successfully bound to the app and notification permissions are enabled, mobile phone information can be synchronised to the watch.

1. Incoming call notification: Enable call reminders in the application. The watch will light up or vibrate when a call is received.
2. SMS notification: Enable SMS notifications in the application. The watch will receive SMS reminders simultaneously with the phone.
3. Other application notifications: Enable notifications for applications like WeChat, QQ, Outlook, and Facebook in the personal application. The watch will receive corresponding reminders simultaneously with the phone.

Frequently used contacts:

Connect to the app, select "Frequently Used Contacts" in the device settings, and add up to 20 contacts. These will be synchronised to the watch and displayed.

Fitness Data:

The fitness data is enabled by default. Enter the fitness data interface and swipe up to display steps, distance, and calories. The data resets daily at midnight.

Smart Mode Selection:

Switching to watch mode disconnects Bluetooth, allowing the watch to function independently and save power. Switching back to smart mode reconnects the watch to the app for more smart functions.

Sports Modes:

Choose a sports mode (e.g., running, cycling, skipping rope, badminton, basketball, football) and tap the start button to begin. Tap the pause button to pause and the end button to stop and save the data.

Data Saving:

Exercise data is saved if the activity lasts longer than 1 minute. If the exercise is too short, it will prompt "Too little data to save".

Additional Exercise Modes:

New modes include gym, yoga, indoor running, and free training.

GPS Tracking:

When the app enters the motion function, the watch will simultaneously start GPS tracking. After the exercise, GPS motion track data will be synchronised from the mobile app to the watch.

Heart Rate:

Wear the watch correctly on your wrist, enter the heart rate menu, and measure your heart rate.

ECG:

Place the watch correctly on your wrist and enter the ECG menu (requires opening the "ECG monitor" interface on the app). You can measure the ECG value once, and the measurement is simultaneously saved in the app. This function requires connection to the app to use.

My QR Code:

Connect the watch to the app, find "My QR Code" on the app interface, and select options like WeChat, QQ, or Alipay "Receive Money QR Code" to save (follow specific instructions in the app).

Calculator:

Perform simple calculations after entering the calculator function.

Remote Music:

When connected to the app, control your phone's music playback (start, pause, previous, next song). Speaker sound appears on the phone.

When on a call via Bluetooth, control phone music playback (start, pause, previous, next song). Speaker sound appears on the watch.

Sleep Monitoring:

Sleep data is generated from 18:00 to 10:00 the next day. After exiting sleep monitoring, sync sleep data from the watch to the app for viewing.

Stopwatch:

Tap to enter the timing interface and record time.

Weather:

After connecting the watch to the app and syncing data, tap "Weather" on the watch to display daily weather information.

Find Mobile Phone:

When the watch is bound to the app, tap to find the phone. The phone will vibrate or ring.

Meteorology:

Tap "Weather" on the watch to display UV and air pressure conditions for the day.

Breathing Exercise:

Select from slow, moderate, or fast breathing modes and follow the selected mode.

Massager:

Tap the green button to start a vibration massage. Tap the red button to end the massage.

Time Setting:

Disconnect from the mobile app and set the time directly on the watch.

Voice Assistant:

After connecting audio Bluetooth, activate the phone's voice assistant (e.g., Siri for iOS, Google Assistant for Android).

Flashlight:

Tap the flashlight icon to fully illuminate the watch screen, acting as a torch.

Female Assistant:

Record women's menstrual cycle status. View data on the app, including the end date of the most recent cycle, cycle length, and days between cycles.

Menu Styles:

Choose from various menu styles. Set a preferred style, which will change the watch's menu layout accordingly.

Settings

1. Language and Data Sync:
 - Select watch language, connect to the app, and synchronize data. Ensure the watch and phone use the same language.

2. Switch Watch Faces:
 - Swipe to browse watch faces, select one, and tap to set as the current watch face.

3. Screen Brightness:
 - Choose from various screen brightness settings.

4. Vibration Intensity:
 - Adjust reminder vibration intensity.

5. Bluetooth Phone:
 - Toggle Bluetooth phone functionality on/off.

6. Password Protection:
 - Set a 4-digit password (if forgotten, enter 8762 to decrypt).

7. Factory Reset:
 - Tap ✓ to initiate a factory reset, or X to cancel.

APP Binding

APP Download: Scan the QR code to download the APP.



For Android Users:

Search for "WearPro" in the Google Play Store or any customised Android Store. Ensure to grant permissions when prompted during installation.

For iOS Users:

Search for "WearPro" in the App Store. Ensure to grant permissions when prompted during installation.

Connecting the APP via Mobile Phone Bluetooth

Search and Connect via Bluetooth Name:

On the watch's main interface, scroll down and select the first icon "About (i)" to view the watch's Bluetooth name.

Open the WearPro app on the mobile phone, navigate to the "Device" section, and select "Search to bind device" to start scanning.

Locate and pair with the watch's Bluetooth name from the list. Successful connection is indicated by a green Bluetooth icon on the watch.

Scan QR Code to Connect:

Pull down on the watch main interface and select "About (i)". Scan the QR code displayed using the WearPro app under "Scan to bind device".

After scanning, a pairing prompt will appear. Click "Pair" to establish the connection.

Ensure to grant notification permissions for various apps.

Connecting the Watch's Audio/Call Bluetooth Channel:

1. Open the Bluetooth settings on your phone.
2. Swipe right on the watch's main interface, tap the "phone call" icon, and select "Open" to view the audio/call Bluetooth name.
3. Pair with the watch's Bluetooth name from the phone's Bluetooth list. A successful connection shows a blue peripheral light around the Bluetooth icon on the watch.

Note: Enable app notification synchronisation permissions in WearPro settings for message viewing on the watch. Ensure both the app and audio Bluetooth are connected to the phone for all functions (e.g., making calls through the watch).

Unbinding Bluetooth Connections from the APP:**Unbinding Bluetooth on Android:**

In the WearPro app's "Device" section, pull down to find and click "Unbind" to disconnect.

Unbinding Bluetooth on iOS:

In the WearPro app's "Device" section, scroll down to find and click "Unbind" to disconnect.

Go to the Bluetooth settings on your phone, select the smartwatch's Bluetooth name, and click "Ignore this device".

Unbinding Audio Bluetooth Connection:

1. To disable the audio Bluetooth connection, go to the Bluetooth settings on your mobile phone.
2. Find the audio Bluetooth name associated with the watch and click "Ignore this device" to unbind all Bluetooth connections.
3. After completing these steps, the watch's Bluetooth icon will return to gray, indicating no active connection.

Find the Device:

Once the watch is successfully bound to the app, click to locate the watch within the mobile app. The watch will vibrate once to indicate its location when the screen is on. Tap the camera icon to activate the watch's camera mode. Press the camera button to capture a photo, which will automatically save to the phone's system album.

Data Synchronisation:

After successfully binding the watch to the app, synchronise data from the watch to the app.

Raise to Wake:

Properly wear the watch on your wrist (left or right hand). Enable the "Raise to Wake" feature. When you raise your wrist to view the watch, the screen will automatically brighten.

Do Not Disturb Mode:

In the app under Device > More, set the start and end times for Do Not Disturb mode (e.g., 12:00 PM to 2:00 PM). During this period, the watch will not ring for calls or notify you of messages.

Daily Alarm Clock:

In the app under Device > More, set single or recurring alarms by selecting specific dates (days of the week). Toggle alarms on or off as needed.

Sedentary Reminder:

Set the start and end times along with the interval (in minutes) for sedentary reminders in the app. Choose to repeat the reminder only once or on specific days (weekly). When the sedentary time interval is reached, the watch will vibrate with a sedentary reminder icon.

Drink Water Reminder:

Configure the start and end times, frequency (in minutes), and repeat settings for water intake reminders in the app. Select specific days (weekly) for reminders. Save the settings, and when it's time to drink water, the watch will vibrate with a water droplet icon.

Dial Push:

Push an Existing Watch Face:

Connect to the app, navigate to Device > Dial Push > Select Dial. Confirm to replace the current watch face with the selected one. After synchronization, the watch will automatically restart and reconnect to the app.

Customize the Watch Face:

Connect to the app, go to Device > Dial Push. Customize the background for dials marked with a pen icon (indicating custom dials). Choose a custom background, synchronize the dial, and the watch will automatically restart and reconnect to the app.